



INSTRUCTION MANUAL FOR BULLPUP

Read the instructions and warnings in this manual carefully before using this firearms

LOADING AND DISHARGING

- 1-** Please take the safety button to S location to safety your gun which located on trigger guard of your gun



- 2-** Release your magazine with the button which locates behind of the magazine



- 3-** Load the magazine as shown.



- 4-** Place the loaded magazine as shown up forward.

LOADING AND DISHARGING

5- Pull the bolt handle back and release. While the bolt is sliding forward magazine carrier will let the cartridge in front of the bolt and the bolt will lock the cartridge in the chamber.



Do not catch the bolt handle while sliding forward. Otherwise the locking will not be done. One cartridge of the magazine capacity

is chambered now. Once a cartridge has been chambered, the magazine may be removed at any time desired for refilling to full capacity. You can now fill another cartridge in to the magazine instead of chambered one. Thus the capacity of your shotgun will be filled. Open the safety latch by pushing from the right side. You will see the red colour. Be carefull and do not touch the trigger during this time. Now your shotgun is ready to lire. When you fire, your shotgun will automatically discharge the fired cartridge and will fill one from the magazine.




6- Release your magazine with the button which locates behind of the magazine

LOADING AND DISHARGING

7- To discharge the cartridge in the chamber, pull back the bolt handle.

Mecanism will discharge the cartridge out while sliding back.



8-Take out the cartridges in the magazine as shown.


9- Bolt will not be released if you pull back the mechanism when there is no cartridges in the magazine.



10- Push the mechanism release button on the left side of case.

LOADING AND DISHARGING

- 11-** Please take the safety button to S location to safety your gun that located on trigger guard of your gun



- 12-** The cocking handle can be used on both sides. Just remove the cocking handle from one side and insert to the other side.

MAINTENANCE OF SHUTGUN



- 13-** Remove the barrel cover located on the muzzle by rotating it counter-clockwise.

- 14-** Please eject the pin with a pointed tool to reassembly the forend





15- The assembly pim that you pushed. Stay in hole and it does not go out completely





16- Reassembly the forend

17- Move to right and left sight the gas chamber to reassembly.



18- Reassembly the piston

19- Clean the gas holes and surface of the barrel with cloth and cleaning oil



20- Clean the inside and the surface of the gas chamber.

21- Clean the inside and the surface of the piston




ASSEMBLING & USAGE



22- Assembly the piston as the picture that narrow side of the piston remains on the outside

23-Assembly the gas chamber as the picture that wide side of the chamber remains on the inside



24-Be sure that piston and gas chamber fully seating to each other



26-Assembly the fixing pin as the picture



27- Screw the barrel cover clockwise.

***PLEASE CLEAN YOUR SHOTGUN EACH TIME AFTER 100 ROUNDS OF SHOOTING OR WHEN YOU RETURN HOME AFTER HUNTING**

***PLEASE USE THE AMMUNITION RECOMMENDED BY THE MANUFACTURER; OTHERWISE, YOUR SHOTGUN WILL BE OUT OF WARRANTY**

- Out of this operations your shotgun will not need more maintenance as user.
- If you need further detailed maintenance or repair get an authorised service.
- Shoot your shotgun after cleaning the protective lubricant.

GUARANTEE TERMS

1- Guarantee period for our goods starts with the delivery date and is two (2) years.

2- If the delivered good doesn't fit the ordered specifications claim and request period for the right product is one (1) month after the delivery date. Claims out of this period will not be accepted and will be understood that the good is accepted with delivered specifications. Good must be sent to us in two (2) months after the delivery date if the claim is accepted. After the report of our experts mentioning that the good is not used and there is not any damage, the right product will be sent to the customer. The period of sending the right product to the customer is three (3) months maximum after receiving the wrong product from the customer.

3- Technical specification of the product is mentioned as "Product identification" in this user's manual.

4- Faults and defects appear and result from the customer/user as; wrong keeping/protedion, maintenance and usage out of the instrudions in this user's manual are out of guarantee coverage.

5- Faults and defects appear and result from the product as; material, workmanship and mounting are in guarantee coverage.

6- Delivery place of the goods is factory sales Office of Salix Arms Goods are delivered to costumer addresses according to their mailing service, courier and shipment choices and our establishment is not responsible for the faults and defects during shipment/delivery.

7- Determining of a defective gun for guarantee coverage never can be done by phone calls, vrritten, visual and digital communication. This determinati-
on can finally be clear after the inspedion of the good by our after sales and guality control experts in the factory.

8-If it is reported by our experts that the product is in guarantee coverage;

'All maintenance, repair and part costs will be at our expense.

*Shipment cost while receiving the produd will be at our expense and shipment cost while sending the repaired produd will be at customer's/owner's expense.

*Number of days during the maintenance and repair of the products in our after sales service will be added to the guarantee period. But in any case the number of the days can not be more than thirty (30).

9-If it is reported by our experts that the defedive products is out of guarantee coverage; customer/user will be informed about the situation and all costs will be at customer's/user's expense even if maintenance and repair not done.

10-Claims and request about our produds can be done direldy to us if it is bought from our factory sales Office. Other wise claims have to be done through retailer, who-lesaler or country distributor where it is bought. Claims out of this will not be valid.

11-Only the customer/user who owns the product registe-red in his/her licence can daim about the product.

12-Claims will not be taken care made without copies of licence and purchasing invoice.

13-In guarantee coverage of our products:

*In case of a report by ourexperts mentioning "the product must be changed,

*And in case if the products is out of usage, defedive product will be changed without any extra cost vwith a new one in same specifications. The perriod of delivering the changed product never can be more than three (3) months.

14-For maintenance, repair and parts Services of our produds please contact your country distributor or conta-ct directly to us for information.

15-Instrudions about the possible dangers for human being, health and nature while using our products is mentioned in this user's manual.

16-For the claims and the problems about the guarantee period and coverage applications can be done to General Diredorate for Protecion of Consumer and Competition Rights under Industry and Trade Ministry.

SAFETY INSTRUCTIONS

Always follow the safety instructions for your safety and the safety of others

-Always handle your firearm as if it were loaded and do not forget firearms are different no matter how much you are experienced.

-Please understand that the first step of safety is yourself. Your shotgun

is a not living object, can not think of safety. It is under your control and using carelessly can cause accidents!

-Never point your firearm at anything you do not intend to shoot and never take anyone's word that the gun is unloaded.

-Never use your shotgun when you are drunk, had drugs, when riding, when driving and when you feel yourself unwell.

-Never shoot at hard surface such as rock, or a liquid surface such as water.

-While shooting use protection material for your eyes and ears.

Always keep your shotgun and cartridges away from the children that they can not reach. If possible in a locked safe place.

Never leave a loaded firearm unattended.

Always use only clean, dry, original high quality commercially manufactured ammunition, which

is appropriate to the gauge of your firearm.

Do not shoot your shotgun without choke tubes and be sure the choke tubes are properly fitted in the muzzle. (On multi choke shotguns only)

Never keep your hand in front of muzzle when shotgun is loaded.

Be careful to follow the instructions correctly and always make sure your firearm is not loaded before/when assembling, dismantling and/or maintaining and cleaning your shotgun to avoid injuries.

Before shooting be sure that inside of the barrel is exactly clean.

Thank You

Thank you for purchasing this shotgun this shotgun with Salix Arms. We are sure this gun will bring you years of hunting and/or shooting pleasure. Your satisfaction is the key to our success. Please let us know if we can be of service and relay any observations about your guns performance or appearance.

Dealer Stamp

salix
A R M S



Model: _____
Serial No: _____
Date: _____

This warranty card is confirmation that you bought your gun from an approved Salix Arms retailer/service centre and confirms that you will get our comprehensive 2 years warranty from the date purchase.

www.salixarms.com •  export@salixarms.com

www.salixarms.com